



---

# **Magellan® 8100/8100Ω 8200/8200Ω**



Model 8204 shown

---

## ***Product Reference Guide***

# TABLE OF CONTENTS

<b>Section 1. Introduction</b>	<b>1-1</b>
Manual Overview	1-2
How to Use This Manual	1-3
Manual Conventions	1-3
Scanner and Scanning-Scale Nomenclature	1-4
Connectors	1-5
Physical Parameters	1-6
Scanning	1-6
Weighing	1-6
Rated Weight Capacity	1-6
Minimum Increment	1-6
Maximum Static Weight (Overload)	1-6
Automatic Zero Maintenance	1-7
Warm-Up Time	1-7
Thermal Equilibrium	1-7
Power-up	1-7
User Configurable Warm-up	1-7
Electrical Specifications	1-9
Power Supply	1-9
Laser and Product Safety	1-10
Labeling	1-12
Bar Codes Supported	1-14
 <b>Section 2. Site Preparation and Installation</b>	 <b>2-1</b>
Pre-Installation Considerations	2-2
Checkstand Design	2-3
Scanner Installation	2-4
Scanner Maintenance	2-4
Ergonomic References	2-4
Scanner Usage	2-4
Site Preparation Overview	2-5
Ventilation and Spacing	2-7
Service Access	2-8
Power Installation	2-9
Grounding	2-9

Checkstand Preparation .....	2-10
Liquid Spills and Moisture .....	2-10
Counter Cutout .....	2-11
Checkstand Mounting .....	2-17
Installation Overview .....	2-17
Unpacking .....	2-17
Operational Verification .....	2-19
Diagnostic Modes .....	2-21
Scanner Diagnostic Mode .....	2-21
Scale Diagnostic Mode .....	2-22
Cables & Connections .....	2-22
Remote Scale Display Placement/Installation .....	2-24
Lighting Considerations .....	2-24
Viewing Angle .....	2-25
Placing and Installing the Remote Scale Display .....	2-26
(Short Pedestal Base ONLY) .....	2-26
Changing Weighing Modes .....	2-29
Set-Up & Installation .....	2-29
Set-up .....	2-29
Installation .....	2-31
System Power-Up Recap .....	2-33
<b>Section 3. Operation and Maintenance .....</b>	<b>3-1</b>
Scanning Items .....	3-1
Proper Scanning Technique .....	3-2
Proper Weighing Technique .....	3-3
Operational Controls .....	3-4
Operational Modes .....	3-4
Power-Up/Selftest & Pre-Operation .....	3-4
Power-Up/Selftest .....	3-4
Error Reporting .....	3-5
Operational Configuration .....	3-5
Operating Mode .....	3-6
Normal Operation .....	3-6
Sleep Mode .....	3-6
Additional Functions .....	3-7
Programming .....	3-7

Diagnostic Mode .....	3-7
Scanner and Scale Reset .....	3-7
Scale Adjustments .....	3-8
Zeroing the Scale .....	3-8
Calibrating the Scale .....	3-8
Operational Maintenance .....	3-10
Vertical Scan Window Replacement .....	3-11
Horizontal Scan Window Replacement (WRG) .....	3-13
<b>Section 4. Problem Isolation.....</b>	<b>4-1</b>
Power-Up Selftest .....	4-1
Operational Tests .....	4-1
Diagnostic Tests .....	4-2
Diagnostic Procedures .....	4-2
Error Codes .....	4-3
Scale Error Reporting .....	4-6
Flowcharts .....	4-8
<b>Section 5. Calibration .....</b>	<b>5-1</b>
Description of Calibration Sequence .....	5-2
Motion Test .....	5-3
Automatic Zero Setting Test .....	5-3
Preparing the Scanner/Scale for Calibration .....	5-4
Calibrating the Scale (Pounds & Kilograms) .....	5-4
Calibration Verification (U.S. Pounds) .....	5-8
Increasing-Load Test (Phase 1) .....	5-9
Shift Test .....	5-9
Increasing- Load Test (Phase 2) .....	5-11
Blanking Test .....	5-11
Decreasing-Load Test .....	5-12
Return to Zero Test .....	5-12
Calibration Verification (Kilograms) .....	5-13
Increasing-Load Test (Phase 1) .....	5-13
Shift Test (Metric) .....	5-14
Increasing- Load Test (Phase 2) .....	5-15
Blanking Test .....	5-16
Decreasing-Load Test .....	5-17
Return to Zero Test .....	5-17

<b>Section 6. Programming</b>	<b>6-1</b>
Introduction to Label Programming	6-1
Understanding the Basics	6-1
Integrating the Scanner With Your Host System	6-1
Customizing Your Scanner's Operation	6-2
Programming Overview	6-3
Programming via Handheld Device	6-3
What Is Programming Mode?	6-4
Entering and Exiting Programming Mode.	6-4
Programming Session	6-5
Programming Sequence	6-7
LED and Beeper Indicators	6-9
If You Make a Mistake...	6-9
Return to Factory Settings	6-9
Test Mode	6-10
General Scanner and Scale Features	6-11
Double Read Timeout	6-11
Laser Timeout	6-13
Motor Timeout	6-15
Green LED Idle State	6-18
Scanner Button Options	6-19
Power-up Beep Control	6-21
Good Read Beep Control	6-23
Good Read Beep Frequency	6-24
Good Read Beep Length	6-26
Good Read Beep Volume	6-27
Good Read When to Indicate	6-30
Scale Enable	6-32
Scale Country Mode	6-33
Scale Enforced Zero Return	6-35
Scale Interface Type	6-37
Scale Motion Level Filter	6-39
Scale LED Enable	6-41
Remote Display — Enable/Disable	6-42
EAS Active State	6-43
EAS Timeout	6-44
Aux Port Mode	6-45

Productivity Index Reporting (PIR) .....	6-47
Interface Related Features .....	6-48
Interface Type .....	6-48
RS-232 Interface Selection .....	6-50
RS-232 Wincor-Nixdorf Interface Selection .....	6-51
RS-232 Single Cable Interface Selection .....	6-52
IBM Port 17 Interface Selection .....	6-53
IBM USB Interface Selection .....	6-54
Maximum Host-Transmitted Message Length .....	6-55
Number of Host Transmission Buffers .....	6-56
Global Prefix .....	6-57
Global Suffix .....	6-59
IBM Features .....	6-61
IBM Interface Options .....	6-61
IBM Scale Address .....	6-62
IBM Transmit Labels in Code 39 Format .....	6-64
IBM USB Interface Options .....	6-65
IBM USB Scanner Device Type .....	6-67
RS-232 Features .....	6-68
RS-232 Baud Rate .....	6-68
RS-232 Number of Data Bits .....	6-72
RS-232 Number of Stop Bits .....	6-73
RS-232 Parity .....	6-74
RS-232 Hardware Control .....	6-76
RS-232 Intercharacter Delay .....	6-78
RS-232 Software Flow Control .....	6-79
RS-232 Host Echo .....	6-80
RS-232 Host Echo Quiet Interval .....	6-81
RS-232 Ignore Host Commands .....	6-82
RS-232 TTL .....	6-83
RS-232 TTL Invert .....	6-84
RS-232 Beep on ASCII BEL .....	6-85
RS-232 Beep After Weigh .....	6-86
RS-232 Beep on Not on File .....	6-87
RS-232 ACK NAK Enable .....	6-88
RS-232 ACK Character .....	6-90
RS-232 NAK Character .....	6-91

RS-232 Retry on ACK NAK Timeout .....	6-92
RS-232 ACK NAK Timeout Value .....	6-93
RS-232 ACK NAK Retry Count .....	6-94
RS-232 ACK NAK Error Handling .....	6-95
RS-232 Label ID Control .....	6-97
Single Cable RS-232 Options .....	6-99
Single Cable RS-232 Scanner Only Protocol .....	6-100
Single Cable RS-232 RTS CTS Selection .....	6-101
Single Cable RS-232 Use BCC .....	6-104
Single Cable RS-232 Use ACK/NAK .....	6-105
Single Cable RS-232 Use STX .....	6-106
Set Single Cable RS-232 STX Character .....	6-107
Single Cable RS-232 Use ETX .....	6-108
Set Single Cable RS-232 ETX Character .....	6-109
Single Cable RS-232 PSC Extensions .....	6-110
Symbology Programming .....	6-111
UPC-A Enable .....	6-111
UPC-A Number System Character Transmission .....	6-112
UPC-A Check Character Transmission .....	6-113
Expand UPC-A to EAN-13 .....	6-114
UPC/EAN AIM ID .....	6-115
UPC-A Label ID .....	6-116
UPC-A 2-Digit Supplemental Label ID .....	6-117
UPC-A 5-Digit Supplemental Label ID .....	6-118
UPC-A 128 Supplemental Label ID .....	6-119
UPC-E Enable .....	6-120
UPC-E Number System Character Transmission .....	6-121
UPC-E Check Character Transmission .....	6-122
Expand UPC-E to UPC-A .....	6-123
Expand UPC-E to EAN-13 .....	6-124
UPC-E Label ID .....	6-125
UPC-E 2-Digit Supplemental Label ID .....	6-126
UPC-E 5-Digit Supplemental Label ID .....	6-127
UPC-E 128 Supplemental Label ID .....	6-128
EAN-13 Enable .....	6-129
EAN-13 First Character Transmission .....	6-130
EAN-13 Check Character Transmission .....	6-131

EAN-13 ISBN Conversion Enable .....	6-132
EAN 13 Label ID .....	6-133
EAN-13 2-Digit Supplemental Label ID .....	6-134
EAN-13 5-Digit Supplemental Label ID .....	6-135
EAN-13 128 Supplemental Label ID .....	6-136
Bookland AIM ID .....	6-137
Bookland Label ID .....	6-138
EAN-8 Enable .....	6-139
EAN-8 Check Character Transmission .....	6-140
Expand EAN-8 to EAN-13 .....	6-141
EAN 8 Label ID .....	6-142
EAN-8 2-Digit Supplemental Label ID .....	6-143
EAN-8 5-Digit Supplemental Label ID .....	6-144
EAN-8 128 Supplemental Label ID .....	6-145
EAN-8 Decoding Levels .....	6-146
Other UPC/EAN Options .....	6-149
UPC/EAN Reconstruction .....	6-150
Price Weight Check .....	6-151
Enable EAN Two Label .....	6-154
Addons .....	6-155
UPC-A and EAN-13 Decoding Levels .....	6-157
GTIN Enable .....	6-160
GTIN Label ID .....	6-161
GTIN 2-Digit Supplemental Label ID .....	6-162
GTIN 5-Digit Supplemental Label ID .....	6-163
GTIN Code 128 Supplemental Label ID .....	6-164
RSS-14 Enable .....	6-165
RSS-14 Check Character Transmission .....	6-166
RSS-14/EAN-128 Emulation .....	6-167
RSS-14 2D Component Enable .....	6-168
RSS-14 AIM ID .....	6-169
RSS-14 Label ID .....	6-170
RSS Expanded Enable .....	6-171
RSS Expanded EAN-128 Emulation .....	6-172
RSS Expanded 2D Component Enable .....	6-173
RSS Expanded AIM ID .....	6-174
RSS Expanded Label ID .....	6-175



RSS Expanded Length Control .....	6-176
RSS Expanded Maximum Label Length .....	6-177
RSS Expanded Minimum Label Length .....	6-178
RSS Expanded Fixed Length 1 .....	6-179
RSS Expanded Fixed Length 2 .....	6-180
Code 39 Enable .....	6-181
Code 39 Start Stop Character Transmission .....	6-182
Code 39 Check Character Calculation .....	6-183
Code 39 Check Character Transmission .....	6-184
Code 39 Full ASCII .....	6-185
Code 39 AIM ID .....	6-186
Code 39 Label ID .....	6-187
Code 39 Length Control .....	6-188
Code 39 Maximum Label Length .....	6-189
Code 39 Minimum Label Length .....	6-190
Code 39 Fixed Length 1 .....	6-191
Code 39 Fixed Length 2 .....	6-192
Code 39 Stitching .....	6-193
Pharmacode 39 Enable .....	6-194
Pharmacode 39 Start Stop Character Transmission .....	6-195
Pharmacode 39 Check Character Transmission .....	6-196
Pharmacode 39 Label ID .....	6-197
Code 128 Enable .....	6-198
Code 128 Transmit Function Characters .....	6-199
Convert Code128 to Code 39 .....	6-200
Code 128 AIM ID .....	6-201
Code 128 Label ID .....	6-202
Code 128 Length Control .....	6-203
Code 128 Maximum Label Length .....	6-204
Code 128 Minimum Label Length .....	6-205
Code 128 Fixed Length 1 .....	6-206
Code 128 Fixed Length 2 .....	6-207
Code 128 Stitching .....	6-208
EAN-128 Enable .....	6-209
EAN 128 AIM ID .....	6-210
EAN 128 Label ID .....	6-211
Interleaved 2 of 5 (I 2 OF 5) Enable .....	6-212

I 2 of 5 Check Character Calculation .....	6-213
I 2 of 5 Check Character Transmission .....	6-214
I 2 of 5 AIM ID .....	6-215
I 2 of 5 Label ID .....	6-216
I 2 of 5 Length Control .....	6-217
I 2 of 5 Maximum Label Length .....	6-218
I 2 of 5 Minimum Label Length .....	6-219
I 2 of 5 Fixed Length 1 .....	6-220
I 2 of 5 Fixed Length 2 .....	6-221
I 2 of 5 Stitching .....	6-222
Codabar Enable .....	6-223
Codabar Start Stop Character Transmission .....	6-224
Codabar Start Stop Character Set .....	6-225
Codabar Start Stop Character Match .....	6-227
Codabar Check Character Calculation .....	6-228
Codabar Check Character Transmission .....	6-229
Codabar AIM ID .....	6-230
Codabar Label ID .....	6-231
Codabar Length Control .....	6-232
Codabar Maximum Label Length .....	6-233
Codabar Minimum Label Length .....	6-234
Codabar Fixed Length 1 .....	6-235
Codabar Fixed Length 2 .....	6-236
Codabar Stitching .....	6-237
Code 93 Enable .....	6-238
Code 93 AIM ID .....	6-239
Code 93 Label ID .....	6-240
Code 93 Length Control .....	6-241
Code 93 Maximum Label Length .....	6-242
Code 93 Minimum Label Length .....	6-243
Code 93 Fixed Length 1 .....	6-244
Code 93 Fixed Length 2 .....	6-245
Code 93 Stitching .....	6-246
MSI/Plessey Enable .....	6-247
MSI/Plessey Check Character Calculation .....	6-248
MSI/Plessey Number of Check Characters .....	6-249
MSI/Plessey Check Character Transmission .....	6-250

MSI/Plessey AIM ID .....	6-251
MSI/Plessey Label ID .....	6-252
MSI/Plessey Length Control .....	6-253
MSI/Plessey Maximum Label Length .....	6-254
MSI/Plessey Minimum Label Length .....	6-255
MSI/Plessey Fixed Length 1 .....	6-256
MSI/Plessey Fixed Length 2 .....	6-257
MSI/Plessey Stitching .....	6-258
Standard 2 of 5 Enable .....	6-259
Standard 2 of 5 Check Character Calculation .....	6-260
Standard 2 of 5 Check Character Transmission .....	6-261
Standard 2 of 5 AIM ID .....	6-262
Standard 2 of 5 Label ID .....	6-263
Standard 2 of 5 Length Control .....	6-264
Standard 2 of 5 Maximum Label Length .....	6-265
Standard 2 of 5 Minimum Label Length .....	6-266
Standard 2 of 5 Fixed Length 1 .....	6-267
Standard 2 of 5 Fixed Length 2 .....	6-268
Standard 2 of 5 Stitching .....	6-269
<b>Appendix A. LED/Beeper Indications &amp; Controls .....</b>	<b>A-1</b>
<b>Appendix B. Cable Information .....</b>	<b>B-1</b>
<b>Appendix C. Keypad .....</b>	<b>C-1</b>
<b>Appendix D. Host Commands .....</b>	<b>D-1</b>
<b>Appendix E. Factory Defaults .....</b>	<b>E-1</b>
<b>Appendix F. Handheld Data Format Requirements .....</b>	<b>F-1</b>
Handheld Data Format Requirements General .....	F-1
PSC Handheld Data Format Requirements .....	F-2
RSS-14 .....	F-2
RSS Expanded .....	F-2
UPC-A .....	F-2
UPC-A with 2-Digit Supplemental .....	F-2
UPC-A with 5-Digit Supplemental .....	F-3
UPC-A with Code 128 Supplemental .....	F-3

UPC-E .....	F-3
UPC-E with 2-Digit Supplemental .....	F-4
UPC-E with 5-Digit Supplemental .....	F-4
UPC-E with Code 128 Supplemental .....	F-4
EAN-8 .....	F-5
EAN-8 with 2-Digit Supplemental .....	F-5
EAN-8 with 5-Digit Supplemental .....	F-5
EAN-8 with Code 128 Supplemental .....	F-5
EAN-13 .....	F-6
EAN-13 with 2-Digit Supplemental .....	F-6
EAN-13 with 5-Digit Supplemental .....	F-6
EAN-13 with Code 128 Supplemental .....	F-6
Code 39 .....	F-7
Code 39-Pharmacode .....	F-7
I 2 of 5 .....	F-7
Codabar .....	F-8
Code 128 .....	F-8
MSI/Plessey .....	F-9
Code 93 .....	F-9
PDF417 .....	F-9
AIM Formats .....	F-10
UPC-A .....	F-10
UPC-E .....	F-10
EAN-13 .....	F-10
EAN-8 .....	F-10
2-Digit Supplemental .....	F-11
5-Digit Supplemental .....	F-11
Code 128 Supplemental .....	F-12
Bookland .....	F-12
Code 39 .....	F-12
Codabar .....	F-13
MSI/Plessey .....	F-13
Code 93 .....	F-13
RSS-14 .....	F-14
RSS Expanded .....	F-14
I 2 of 5 .....	F-14
Code 128 / EAN128 .....	F-15



This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*